


KAGULUX HE | SE BACKLIT PANEL INSTALLATION GUIDE

NEEDED FOR MOUNTING



PANEL DIMENSIONS (mm)



WARNING

- Turn power off before inspection, installation or removal.
- Properly ground electrical enclosure.
- Luminaire may fall down if not installed properly.
- Avoid direct eye exposure to the light source while it is on.
- For indoor use only.
- Dry location only.
- Do not operate luminaire with damaged parts.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.

The manufacturer shall not be liable for any damage resulting from inappropriate modifications to the luminaire or faulty installation.

If you have any questions, contact the manufacturer.


© 2023, All rights reserved BaltLED, UAB. Specifications are subject to change without notice.





KAGULUX HE | SE BACKLIT PANEL INSTALLATION GUIDE

RECESSED MOUNTING




© 2023, All rights reserved BaltLED, UAB. Specifications are subject to change without notice.






KAGULUX HE | SE BACKLIT PANEL INSTALLATION GUIDE

RECESSED MOUNTING



CONNECTION DIAGRAM



© 2023, All rights reserved BaltLED, UAB. Specifications are subject to change without notice.

